The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.

# Onan


# Parts Manual

4.0 & 5.0

BGA GenSet

**RV Electric Generating Set** 


965-0221 2-86 (Specs A-D) replaces 9-83 (SPECS A-C) Printed in U.S.A.



#### **General Information**

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.



For handy reference, insert "YOUR" nameplate information in the spaces above.

#### Index

Adapter, Choke 20 Housing, Choke 20 Adapter, Generator 28 Joint, Ball 10 Kit, Carburetor Air Preheater 48 Arm And Shaft, Governor 11 Armature, Generator 28 Kit, Carburetor Repair 22, 24 Base, Oil 14 Kit, Gasket 6, 12, 22, 24, 27 Bearing, Camshaft 4 Kit, Tune-up 27 Bearing, Crankshaft 4 Line, Fuel-Gasoline 20 Bell, End 28 Linkage, Governor 10 Block, Brush 28 Manifold, Exhaust 39, 44, 46 Block, Cylinder 4 Manifold, Intake 20 Block Terminal 32 Meters, Remote Control 41 Box, Breaker 26, 27 Muffler Exhaust 44, 46 Bracket, Governor 10 Paint, Green 48 Breaker, Circuit 34 Pan, Oil Base 16 Brush, Generator 28 Panel, Control 41 Camshaft 8 Pin, Drive 4 Carburetor, Gasoline 20, 22, 24 Piston 9 Carburetor, LP 42 Plate, Bearing-Rear 4 Clamp, Muffler 44, 46 Plate, Mounting 16 Coil, Ignition 26 Plug, Expansion 4 Control, Generator 32, 34, 36 Plug, Spark 26 Control, Remote 41 Points, Ignition 27 Cover, Air Cleaner 13 Pump, Fuel-Electric (Gasoline) 20 Cover, Control 32 Pump, Oil 12 Cover, Valve 6 Reed, Breather Valve 6 Crankshaft 8 Regulator, LP 42 Cushion, Vibration 14 Resistor, Fixed 28 Duct. Air Cleaner 13 Ring, Piston 9 Element, Air Cleaner 13 Rod, Connecting 9 Fan, Generator 30 Rod, Governor 10 Filter, Breather Tube 20 Seal, Oil-Crankshaft 4 Filter, Oil 12 Seal, Valve-Intake 6 Flywheel 8 Seat. Valve 4 Fuse, 5 Amp 32 Scroll, Air Housing 38 Gasket, Exhaust Manifold 39, 44, 46 Shield, Heat 46 Gasket, Gearcase 11 Solenoid, Start 32 Gasket, Head 6 Spring, Governor 10 Gasket, Oil Base 14 Stator, Generator 28 Gasket, Valve Cover 6 Strap, Ground 16 Gear, Camshaft 8 Switch, Pressure—Oil 12 Gearcase 11 Switch, Rocker-Control 32 Generator 28, 30 Tappet, Valve 6 Guard, Scroll 38 Tube, Breather 20 Guide, Valve 4 Tube, Exhaust 44, 46 Hanger, Exhaust 44, 46 Valve, Exhaust 6 Harness, Wiring (Control to Engine) 34 Valve, Intake 6 Harness, Wiring—Remote 36, 41 Valve, Magnetic 42 Head, Cylinder 6 Valve, Shutoff-Fuel (LP) 42 Hose, Duct 48 Yoke, Governor 11

Housing, Air 38

#### Introduction

This catalog applies to the standard BGA Recreational Vehicle Generator Sets and factory installed options. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the *Model* and *Spec No.* from the nameplate, select *Parts* that apply to your set *Model* and *Spec No.* Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left sides are determined by facing the engine end (front) of the set.


#### **Data Table**

Model And	Electrical Data					
Spec No.	Watts	Hertz	Volts	Phase		
5.0 BGA-3CR/*	5,000	60	120/240	1		
4.0 BGA-53CR/*	4,000	50	120/240	1		

<sup>\* -</sup> This Specification Letter Advances (A to B, B to C, etc.) with Manufacturing Changes.

### **NOTICE!**


ITEMS REFERENCED AS **OPTIONAL** INDICATE PART IS FACTORY INSTALLED AND MAY NOT BE APPLICABLE TO ALL MODELS. FOR FIELD CONVERSIONS ADDITIONAL PARTS ARE USUALLY REQUIRED.



## Cylinder Block

Ref. No.	Part No.	Qty. Used	Part Description
1	110-3148	1	Block Assembly, Cylinder (Includes Parts Marked *)
2	800-0051	5	*Screw, Cap - Hex Head (3/8-16 x 1-1/4")
3	850-0050	5	*Washer, Lock - Spring (3/8")
4	509-0041	1	*Seal, Oil - Crankshaft Rear
5	516-0072	4	*Pin, Drive - Bearing Stop
6	104-0776	As Req.	*Shim (.005")
7			- REAR (Includes Thrust Washer)
	101-0450	1	*Standard
	101-0450-02		.002" Undersize
	101-0450-10		.010" Undersize
	101-0450-20		.020" Undersize
	101-0450-30	1	.030" Undersize
8	104-0575	2	*Washer, Thrust
9	101-0415	1	*Gasket
10	101-0439	1	*Plate, Bearing - Rear
11	517-0048	1	*Plug, Expansion - Welch
12 13	110-0068	2	*Gasket, Intake Valve Guide
13	GUIDE, VALV		Juan Caralla
	Engines w/o 110-1935	intake va 2	ilve Seals Intake
	110-1935	2	
	Engines wit		Exhaust
	110-1935	1111take 1	*Exhaust
	110-3161	2	*Intake
14	101-0405	2	*Bearing, Camshaft
15	BEARING, CR.		
	101-0432	1	*Standard
	101-0432-02		.002" Undersize
	101-0432-10	1	.010" Undersize
	101-0432-20	1	.020" Undersize
	101-0432-30	1	.030" Undersize
16	120-0735	1	*Tube, Oil Crankcase
17	INSERT, VAL		
	110-1824	2	*Standard
	110-1824-02	2	.002" Oversize
	110-1824-05	2	.005" Oversize
	110-1824-10 110-1824-25	2 2	.010" Oversize .025" Oversize
18	INSERT, VAL		
10	110-0197	2	*Standard
	110-0197-02	2	.002" Oversize
	110-0197-05	2	.005" Oversize
	110-0197-10	2	.010" Oversize
	110-0197-25	2	.025" Oversize
19	516-0141	2	*Pin, Gearcase Alignment
20	800-0010	2	Screw, Cap - Hex Head
	<del>-</del> -	_	$(1/4-20 \times 1-3/4")$
21	526-0063	2	Washer, Flat - Copper (17/64" ID x 7/16" GD x 1/32" Thk)
* - Pa	arts Included	in 110-314	8 Cylinder Block Assembly.
			·

<sup>5</sup> 




## Cylinder Block

110-2274   1	Ref. No.	Part No.	Qty. Used	Part Description
23	22	110-2274	1	Cover, Valve (With Breather Port)
X 1/16" Thk)	23		1	Spring, Breather Valve
25	24	526-0018	1	Washer, Flat (17/64" ID x 5/8" OD
26	25	123-1175	1	
110-1879		123-1173	1	
29	27	110-1879	1	Cover, Valve (Without Breather
29	28	110-1921	3	Gasket. Valve Cover
HEAD, CYLINDER				Washer, Flat (11/32" ID x 23/32" OD
110-2562	30	HEAD. CYLIND	ER	
110-2561				Right Side
31				
110-2267 2 Standard 116-3181 2 Graphoil (Cptional)  32 SCREW, CAP - HEX HEAD 800-0540 12 Special (Grade 8) 800-0541 12 Special (Grade 8)  33 TAPPET, VALVE 115-0006 4 Standard 110-0066-02 4 .002" Oversize 115-0006-05 4 .005" Oversize 34 110-639 8 Lock, Valve Spring 35 110-0904 4 Rotocap, Valve 36 110-0539 4 Spring, Valve 37 110-1808 2 Valve, Intake  8 VALVE, EXHAUST 110-1955 2 Spec A, B, C 110-1809 2 Begin Spec D 39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional	31			
116-3181   2     Graphoil (Cptional)		-	2	Standard
SCREW, CAP - HEX HEAD   800-0540   12   Special (Grade 8)   800-0541   12   Special (Grade 8)				
800-0540 12 Special (Grade 8) 800-0541 12 Special (Grade 8)  33 TAPPET, VALVE  115-0006 4 Standard 110-0006-02 4 .002" Oversize 115-0006-05 4 .005" Oversize 34 110-0639 8 Lock, Valve Spring 35 110-0904 4 Rotocap, Valve 36 110-0539 4 Spring, Valve 37 110-1808 2 Valve, Intake 38 VALVE, EXHAUST 110-1955 2 Spec A, B, C 110-1809 2 Begin Spec D 39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional	32		HEX HEAD	·
800-0541 12 Special (Grade 8)  33 TAPPET, VALVE		<u>-</u>		Special (Grade 8)
115-0006				
115-0006	33	TAPPET, VALV	E	•
110-0006-02 4 .002" Oversize 115-0006-05 4 .005" Oversize 34 110-0639 8 Lock, Valve Spring 35 110-0904 4 Rotocap, Valve 36 110-0539 4 Spring, Valve 37 110-1808 2 Valve, Intake 38 VALVE, EXHAUST 110-1955 2 Spec A, B, C 110-1809 2 Begin Spec D 39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional				Standard
115-0006-05			4	.002" Oversize
34			4	.005" Oversize
35	34	110-0639	8	Lock, Valve Spring
36		110-0904	4	
38 VALVE, EXHAUST  110-1955	36	110-0539	4	
110-1955 2 Spec A, B, C 110-1809 2 Begin Spec D 39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional 43 KITS	37	110-1808	2	Valve, Intake
110-1809 2 Begin Spec D 39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional	38	VALVE, EXHAU	ST	
39 517-0120 1 Plug, Cylinder Block Opening 40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional 43 KITS		110-1955	2	Spec A, B, C
40 517-0067 1 Plug, Core Hole 41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional 43 KITS		110-1809	2	Begin Spec D
41 509-0168 2 Seal, Valve - Intake 42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional 43 KITS	39	517-0120	1	Plug, Cylinder Block Opening
42 110-0893 2 Washer, Intake Valve Spring Retainer - Optional 43 KITS	40	517-0067		Plug, Core Hole
Retainer - Optional 43 KITS	41	509-0168		
43 KITS	42	110-0893		
	13	KITS		ne ta mer op trona i
100 0177 1 003KE 6 N 1 6 6 001 DON NEWOTA 1	40		1	Gasket Kit Carbon Removal
168-0143 1 Gasket Kit, Engine				

<sup>\* -</sup> Parts Included in 110-3148 Cylinder Block Assembly.

#### Camshaft




Ref. No.	Part No.	Qty. Used	Part Description
1	150-0078	1	Ring, Retaining
2	150-1695	1	Kit, Governor Cup Replacement (Includes Parts Marked *) - Spec A
3	510-0015	10	Ball, Governor
4	105-0332	1	Gear Assembly, Camshaft (Includes Parts Harked †)
5	150-1510	1	tSpacer, Flyballs
G	150-0077	1	tPlate, Flyball
7	105-0541	1	Washer, Thrust - Special
$\epsilon$	515-0001	1	Key, Woodruff
ن	105-0376	1	Camshaft (Includes Center Pin)
10	150-0075	1	Pin, Center - Camshaft
11	150-1519	1	*Hub, Governor Cup - Begin Spec ಕ
12	150-1520	1	*Cup and Bushing, Governor - Begin Spec B
13	105-0030	1	†Gear, Camshaft

\* - Parts Included in 150-1695 Governor Cup Kit.

t - Parts Included in 105-0332 Camshaft Gear Assembly.

### Crankshaft and Flywheel



104-1348

515-0103

10

11

2


Crankshaft (Kit)

\*Key, Crankshaft Stub

(Includes Parts Narked \*)


<sup>\* -</sup> Parts Included in 104-1348 Crankshaft Kit.

#### Piston and Rod



Ref. No.	Part No.	Qty. Used	Part Description
1	PISTON AND PI	N ASSEMB	LY (Includes Retaining Rings)
	112-0186	2	Standard
	112-0186-05		.005" Oversize
	112-0186-10	2 2	.010" Oversize
	112-0186-20	2 2 2	.020" Oversize
	112-0186-30	2	.030" Oversize
	112-0186-40	2	.040" Oversize
2	112-0229	2	Pin, Piston
3 4	518-0311	4	Ring, Retaining
4	RING SET, PIST	ГОИ	
	113-0189	2	Standard
	113-0189-05	2	.005" Oversize
	113-0189-10	2	.010" Oversize
	113-0189-20	2 2 2 2	.020" Oversize
	113-0189-30	2	.030" Oversize
	113-0189-40	2	.040" Oversize
5	ROD, CONNECTIN	G (Inclu	ides Bolt and Nut)
	114-0257	2	Standard
	114-0257-10	2	.010" Undersize
	114-0257-20	2 2 4	.020" Undersize
	114-0257-30	2	.U30" Undersize
6	114-0228	4	Bolt, Special - Connecting Rod
7	870-0137	4	Nut, Self-Locking (5/16-24)


## Governor



Ref. No.	Part No.	Qty. Used	Part Description
1	870-0131	1	Nut, Hex - Self-Locking (1/4-20)
2	150-0096	1	Stud, Speed Adjustment
3	150-1612	1	Spring, Governor
3 4	800-0004	2	Screw, Cap - Hex Head (1/4-20 x 5/8")
5	526-0063	2	Washer, Flat - Copper (17/64" ID x 7/16" OD x 1/32" Thk)
6	150-1577	1	Bracket, Governor
7	518-0004	1	Clip, Retaining
8	870-0131	1	*Nut, Hex - Self-Locking (1/4-20)
9	150-0629	1	*Rod, Governor Arm to Carburetor
10	870-0053	1	*Nut, Hex (#10-32)
11	150-0639	1	*Joint, Ball
12	149-0003	1	Gasket, Governor Bracket
13	150-0678	1	Clip, Sensitivity Adjustment
14	150-0630	1	Linkage, Governor (Includes Parts Narked *)

<sup>\* -</sup> Parts Included in 150-0630 Governor Linkage


#### Gearcase




Ref. No.	Part No.	Qty. Used	Part Description
1	103-0667	1	Gearcase Assembly (Includes Parts Marked *)
2	150-1542	1	*Arm and Shaft, Governor
2 3	509-0008	1	*Seal, Oil - Governor Shaft
4 5	510-0013	2	*Bearing, Needle
5	510-0014	1	*Ball, Bearing
6	516-0130	1	*Pin, Governor Cup Stop
7	150-1187	1	*Yoke, Governor
3	815-0046	2	*Screw, Machine - Pan Head (#8-32 x 3/8")
9	509-0040	1	*Seal, Oil - Crankshaft
10	103-0408	1	Gasket, Gearcase
11	526-0065	5	Washer, Flat - Copper (21/64" ID x 9/16" OD x 1/16" Thk)
12	SCREW, CAP 800-0032 800-0034	- HEX HEAD 4 1	
13	150-0678	1	*Clip, Sensitivity Adjustment

<sup>\* -</sup> Parts Included in 103-0667 Gearcase Assembly


# Oil System






Ref. No.	Part No.	Qty. Used	Part Description
1	122-0320	1	Adapter, Oil Filter
2	122-0321	1	Gasket, Oil Filter Adapter
			Mounting
3	122-0645	1	Filter, Oil - Spin-on
4	122-0347	1	Seal, Air - Oil Filter
5 6	122-0360	1 1	Drain, Oil Filter
	502-0053		Elbow, Street - 45°
7	309-0322	1	Switch, Low Oil Pressure
8	800-0028	2	Screw, Cap - Hex Head (5/16-18 x 1")
9	526-0065	2	Washer, Flat - Copper (21/64" ID x 9/16" OD x 1/16" Thk)
10	815-0194	2	Screw, Tapping - Hex Head (#10-32 x 3/8")
11	336-3377	1	Lead, Oil Pressure Switch
12	526-0066	ĩ	Washer, Flat - Copper (25/64" ID
		_	x 9/16" OD x 1/16" Thk)
13	801-0050	1	Screw, Cap - Hex Head (3/8-24 x 1")
14	120-0140	1	Spring, Oil By-Pass Valve
15	120-0398	1 2	Valve, Oil By-Pass
16	850-0040		Washer, Lock - Spring (1/4")
17	800-0007	2	Screw, Cap - Hex Head (1/4-20 x 1")
18	120-0491	1	Pump, Oil (Components Not Sold Separately)
19	120-0161	1	Kit, Gasket - Oil Pump
20		_	(Includes Screw Pipe and Cup)
	120-0648	1	Spec A
	120-0413	1	Begin Spec B

## Air Cleaner




	10		
Ref. No.	Part No.	Qty. Used	Part Description
1	140-1520	1	Clamp, Air Buct
2	140-1502	1	Seal, Air Duct to Adapter
2 3 4	518-0390	2	Screw, Wing (1/4-20 x 3/4")
4	526-0021	1	Washer, Flat (17/64" ID x 3/4" OD x 1/16" Thk)
5 6	140-1503	1	Duct, Air Cleaner
6	140-1531	1	Bracket, Air Duct Support
7	821-0009	3	Screw, Cap - Hex Head Locking (1/4-20 x 3/8")
8	140-1521	1	Seal, Air Duct to Breather Port
9	870-0212	1 2 1 2	Hut, Hex - Locking (1/4-20)
10	865-0019	1	Nut, King (1/4-20)
11	526-0158	2	Washer, Flat (.261" ID x 1" OD x 1/8" Thk)
12	870-0212	1	hut, Hex - Locking (1/4-20)
13	816-0070	1	Bolt, Carriage (1/4-20 x 6-1/2")
14	140-0495	1	Element, Air Cleaner
15	140-1504	1	Cover, Air Cleaner
16	140-1522	1	Spacer, Air Intake
17	140-1529	1	Bracket, Air Intake Duct
18	140-1528	1	Brace, Air Intake Duct
19	140-1533	2	Seal




Ref. No.	Part No.	Qty. Used	Part Description
1	BASE, OIL		
	102-0944	1	Spec A (Includes Plug)
	102-0957	1	Begin Spec B (Includes Parts Marked *)
2	GASKET, O	IL BASE	
	102-1200	1	Spec A
	102-1200	1	*Begin Spec B
3	526-0013	4	Washer, Flat (25/64" ID x 1" OD x 1/16" Thk) - Begin Spec B
4		NDICATOR,	
	123-0489	1	Spec A
	123-1400	1	Begin Spec B
5	123-0191	1	Gasket, Oil Fill Cap
6 7	504-0092	1	Valve, Oil Drain
7	505-0019	1	Reducer, Pipe (1/2" x 3/8") - Spec A
3	102-1275	1	*Gasket, Oil Pan Hounting
9	102-0889	1	*Pan, Oil Base
16	821-0018	20	*Screw, Cap - HVH (1/4-20 x 5/8")
12	800-0047	1	Screw, Cap - Hex Head (3/8-16 x 5/8") - Spec A
13	856-0010	1	Washer, Lock - EIT (3/8") - Spec A
14	PACKAGE,	HARDWARE M	OUNTING (Includes Parts Marked #)
	402-0435	1	Spec A
			Begin Spec B
	402-0477	1	Engine End
	402-0478	1	Generator End (Left Side)
	402-0480	1	Generator End (Right Side)
15	#CUSHION,	VIBRATION	- ENGINE END
	402-0283	2	Spec A
	402-0283	2	Begin Spec B
16	#CUSHION,	VIBRATION	- GENERATOR END
	402-0284	1	Spec A
			Begin Spec B
	402-0283	1	Left Side
	402-0283	1	Right Side
17	#SPACER, S	LEEVE	
	402-0290	3	Spec A
			Begin Spec B
	402-0290	2	Engine End
	402-0290	1	Generator End (Left Side)
	402-0290	1	Generator End (Right Side)
18	#SNUBBER		
	402-0282	3	Spec A Begin Spec B
	402-0282	2	Engine End
	402-0282	1	Generator End (Left Side)
	402-0282	1	Generator End (Right Side)

<sup>\* -</sup> Parts Included in 102-0957 Oil Base.# - Parts Included in Hardware Mounting Package.



Ref. No.	Part No.	Qty. Used	Part Description
19	800-0682	3	#Screw, Cap - Hex Head (7/16-14 x 3-3/4") - Spec A
20	526-0195	3	#Washer, Flat (29/64" ID x 3-1/4" OD x 1/8" Thk) - Spec A
21	#NUT, HEX (7/	16"-14)	• • • • • • • • • • • • • • • • • • • •
	862-0004	3	Spec A
			Begin Spec B
	862-0004	2	Engine End
	862-0004	1	Generator End (Left Side)
	862-0004	1	Generator End (Right Side)
22	#WASHER, LOCK	(7/16")	
	856-0012	3	Spec A
			Begin Spec B
	850-0055	2	Engine End
	850-0055	1	Generator End (Right Side)
23	#WASHER, FLAT	(29/64"	ID x $1-1/2$ " OD x $1/8$ " Thk)
	526-0014	3	Spec A
			Begin Spec B
	526-0014	2	Engine End
	526-0014	1	Generator End (Left Side)
	526-0014	1	Generator End (Right Side)
24			D x 1-1/2" OD x 1/16" Thk)
	526-0198	6	Spec A
	3-1 4-10	•	Begin Spec B
	526-0198	4	Engine End
	526-0198	2	Generator End (Left Side)
	526-0198	1	Generator End (Right Side)
25	#WASHER, FLAT	(1.12"	ID x 1.75" OD x .183" Thk)
	526-0286	1	Generator End (Left Side) - Begin Spec B
	526-0286	1	Generator End (Right Side) -
	320 0200	•	Begin Spec B
26	#WASHER, FLAT	(41/64"	ID x 1-1/4" UD x 1/8" Thk)
	526-0038	1	Right Side Generator End -
	727 0000	-	Begin Spec B
	526-0038	2	Engine End
27	SCREW, CAP -		
	800-0051	4	3/8-16 x 1-1/4" - Spec A
	800-0064	4	3/8-16 x 4-1/2" - Begin Spec B
28	850-0050	4	Washer, Lock - Spring (3/8")
29	STRAP, GROUN		nasher; Lock opining (5/6 /
	337-0049	1	Spec A
	337-2055	1	Begin Spec B
30	815-0350	1	Screw, Tapping - Slotted Head
	010 0000	•	(#10-32 x 3/8")
31	122-0345	1	Hose, Oil Drain - Optional
32	PLATE, MOUNT		
32	-	_	Spac A
	403-1219	1	Spec A
	403-1484	1	Begin Spec B


<sup># -</sup> Parts Included in Hardware Hounting Package.



	Ref. No.	Part No.	Qty. Used	Part Description
33	€62-0001	1	Nut, Hex (1/	4-20) - Spec A
34	856-0008	1		- EIT (5/16") -
35		AGE (7/1	Spec A 6-14 x 3-1/2") -	Begin Spec B
	816-0206	2	Engine End	
	816-0206	1	Generator En	d (Left Side)
	816-0206	1	Generator En	d (Right Side)
36	526-0030	4		: - Begin Spec C
				$6 \times 7/8$ " OD x 1/8" Thk)
37	816-0197	1	tBolt, Carria	ge (7/16-14 x 1-1/4")
38	856-0016	1	tWasher, Lock	- EIT (5/8")
39	862-0004	1	tNut, Héx (7/	16-14)
40	856-0012	1		- EIT (9/16")
41	850-0055	1	Washer, Lock	

<sup>\* -</sup> Parts Included in 102-0957 Oil Base.


<sup># -</sup> Parts Included in Hardware Mounting Package. † - Use with 337-2055 Ground Strap.



## Fuel System

Ref. No.	Part No.	Qty. Used	Part Description
1	123-1417	1	Filter, Breather Tube
2	503-0280	1	Clamp, Hose
3	123-1277	1	Tube, Breather
4	503-0769	1	Clamp, Hose
5	140-1492	1	Adapter, Air Duct
6	CARBURETOR,	COMPLETE	(See Separate Page for Components)
	(Includes M	<b>ountin</b> g Ga	
	146-0308	1	WALBRO
_	146-0419	1	NIKKI
7	154-0733	1	Gasket, Carburetor to Adapter
8	154-1977	1	Adapter, Carburetor
9	145-0438	1	Gasket, Manifold to Carburetor Adapter
10	800-0028	2	Screw, Cap - Hex Head (5/16-18 x 7/8")
11	850-0045	2	Washer, Lock - Spring (5/16")
12	800-0023	2	Screw, Cap - Hex Head
			$(1/4-20 \times 1-3/8")$
13	850 <b>-</b> 6040	2	Washer, Lock - Spring (1/4")
14	154-2206	1	Hanifold, Intake
15	154-1446	2	Gasket, Intake Manifold
16	800-0033	4	Screw, Cap - Hex Head
			(5/16-18 x 2")
17	850-0045	4	Washer, Lock - Spring (5/16")
18	502-6003	1	Connector, Inverted Male
19	149-1531	1	Line, Fuel
20	518-0350	1	Clamp, Loop - Insulated
21	862-0015	1	Nut, Hex (5/16-18)
22	502-0002	1	Elbow, Inverted Male
23	502-0395	1	Connector, Hose
24	149-1828	1	Pump, Fuel (Electric)
25	ELBOW, 90°	_	
	502-0313	1	Begin Spec B
0.0	502-0196	1	Spec A
26	332-0529	1	Terminal, Fuel Pump Lead
27	821-0008	2	Screw, Cap - Self-Locking (1/4-20 x 5/16" lg)
28	153-0058	1	Housing, Choke
29	153-0017	1	Bi-Netal, Choke
30	153-0114	1	Element & Choke Cover
31	332-0527	1	Terminal, Lug
32	815-0285	2	Screw, Machine - Round Head W/ET (#8-32 x 5/16")
33	526-0062	2	Washer, Flat - Brass (.02" ID x 1/2" OD x 1/16" Thk)
34	815-0110	1	Screw, Machine - Fillister Head (#10-32 x 7/8")
35	850-0030	1	Washer, Lock - Spring (#10)
36	332-0556	1	Connector, Fuel Pump Lead
37	804-0017	3	Screw, Socket Head (#10-32 x 1/2" lg)
38	153-0499	1	Adapter, Choke
39	815-0359	2	Screw, Self-Tapping - Hex Head (#10-32 x 7/8" lg)
40	509-0145	1	Seal, "O" Ring

# Carburetor Parts (Walbro) Gasoline




# Carburetor Parts (Walbro) Gasoline

Ref. No.	Part No.	Qty. Used	Part Description
	146-0308	1	Carburetor - Complete (Includes Mounting Gasket)
	146-0220	1	*Kit, Gasket Replacement
1	146-0248	1	*Power Needle Package
2	146-0209	1	*Idle Needle Package
3	146-0208	1	*Spring Buoyancy
4	146-0289	1	*Valve and Seat Package
5	146-0222	. 1	*Screw, Lever Pin
6	146-0243	1	Jet, Power
7	146-0261	1	Idle Speed Adjusting Screw Package
8	146-0262	1	Float Package
ς	146-0267	1	Throttle Shaft Package
10	146-0247	4	Screw, Body to Intake
11	146-0142	4	Screw, Valve Mounting
12	146-0265	1	Choke Shaft Package
13		1	Intake, Air (Not Sold Separately)
14		1	Body (Not Sold Separately)
15	146-0290	1	Kit, Repair (Includes Parts Marked *)

<sup>\* -</sup> Parts Included in 146-0290 Repair Kit.

### Carburetor Parts (Nikki) Gasoline




# Carburetor Parts (Nikki) Gasoline

Ref. No.	Part No.	Qty. Used	Part Description
	146-0419	1	Carburetor, Complete (Includes Hounting Gasket)
1	146-0417	1	Choke, Shaft Kit
2	146-0418	i	Shaft, Throttle (Kit)
1 2 3 4	146-0322	1	*Screw and Plug Kit
Λ	146-0326		
		1	*Gasket, Kit
5 6	146-0325	1	Float, Kit
	146-0329	1	*Valve and Seat Kit
7 8	146-0343	1	Jet, Power
3	146-0420	1	Jet, Idle
9	146-0335	1	*Needle, Idle Adjusting
10	146-0331	1	*Spring, Idle Adjusting Needle
11		1	Intake, Air (Not Sold Separately)
12		1	Body (Not Sold Separately)
13	154-0733	1	*Gasket, Carburetor Mounting
14	146-0327	1	Variable Jet Kit - Optional (High
		_	Altitude Application) (Includes
			Parts Narked +)
15	146-0343	1	+Power Jet, Variable (Includes
10	140 0545	1	Gasket)
16	146-0340	1	+Retainer, Power Needle (Includes
		_	Gasket)
17	146-0341	1	+Spring, Power Needle
18	146-0342	1	+Needle Complete, Power
19	145-0438	1	*Gasket, Carburetor Mounting
20	146-0356	1	
20	140-0350	1	Kit, Repair (Includes Parts Harked *)


<sup>\* -</sup> Parts Included in 146-0356 Repair Kit.+ - Parts Included in 146-0327 Variable Jet Kit.

## Ignition System




No.	No.	Used	Description
1	166-0643	1	Coil, Ignition
2 3	166-0588	1	Clamp, Coil
3	815-0350	1	Screw, Cap - Hex Head (#10-32 x 1/2")
4	870-0131	1	Nut, Hex - W/ET (#10-32)
5	312-0017	1	Condenser
6	167-1602	2	Cable, Spark Plug
7	160-0558	2	Nipple, Spark Plug Cable
8	160-1303	1	Box Assembly, Breaker (See Separate Page for Components) Includes Hounting Gasket
9	160-1150	1	Gasket, Breaker Box Mounting
10	336-2378	1	Lead, Coil to Breaker Points
11	160-1151	1	Plunger, Breaker Points
12	PLUG, SPARK		•
	167-0237	2	Spec A
	167-0298	2	Begin Spec B
13	166-0554	2	Nut, Hex (Special)
14	850-2005	2	Washer, Lock - Spring (Metric)
15	802-0034	2	Screw, Cap - Socket Head (1/4-20 x 3/4")
16	850-0038	2	Washer, Lock - Spring (1/4")

# **Ignition Breaker Box Assembly**




	10		14 ES 1057
Ref. No.	Part No.	Qty. Used	Part Description
	160-1303	1	Box Assembly, Breaker - Complete (Includes Parts Marked *)
1 2	509-0065	1	*Retainer, Breaker Box Cover Screw
2	802-0022	1	*Screw, Cap - Socket Head (#10-24 x 1-1/2")
3	526-0008	1	*Washer, Flat (13/64" ID x 7/16" OD x 1/32" Thk)
4	160-1285	1	*Cover, Breaker Box (Includes Screw, Washer and Retainer)
5	815-0358	1	*Screw, Cap - Hex Head (#8-32 x 5/16")
7 8	312-0246	1	t*Condenser, Ignition
	802-0034	2	*Screw, Cap - Socket Head (1/4-20 x 3/4")
9	850-0038	2	*Washer, Lock - Spring (1/4")
10	160-1183	1	t*Point Assembly, Breaker
11	160-1219	1	*Base, Breaker Box
12	160-1150	1	*Gasket, Breaker Box
14	336-2378	1	Lead, Breaker Box to Coil
15	160-1311	1	<pre>Kit, Ignition Tune-Up (Includes     Parts Harked †)</pre>
16	542-8223	1	Kit, Ignition Tune-Up (Includes Points, Condenser and Spark Plugs)

<sup>\* -</sup> Parts Included in 160-1303 Breaker Box Assembly. † - Parts Included in 160-1311 Ignition Tune-Up Kit.




Ref. No.	Part No.	Qty Use	
1	862-0015	4	Nut, Hex (5/16-18)
2	231-0164	1	Adapter, Generator to Engine
			(Includes 4-516-0196 Alignment
			Pins)
3	850-0050	4	Washer, Lock - Spring (3/8")
4	800-0050	4	Screw, Cap - Hex Head (3/8-16 x 1-1/4")
5	520-0733	1	Stud, Armature Through
6			(Includes Parts Harked *)
·	201-2407	1	60 Hertz
	201-2408	1	50 Hertz - Spec A
	201-2506	1	50 Hertz, Begin Spec B
7	204-0110	$\bar{1}$	*Ring, Collector
8	203-0152	1	*Commutator
9	510-0047	1	*Bearing, Ball
10	STATOR		•
	220-1821	1	60 Hertz
	220-1822	1	50 Hertz
11	516-0196	8	Pin, Alignment
12	860-0008	1	Nut, Hex (#8-32)
13	304-0014	2	Washer, Centering - Resistor
14	353-0060	1	Resistor, Fixed (7.5-0hm, 25 Watt)
15	850-0025	1	Washer, Lock - Spring (#8)
16	812-0092	1	Screw, Machine - Round Head (#8-32 x 3/4")
17	800-0044	4	Screw, Cap - Hex Head
10	050 0645		$(5/16-18 \times 5")$
18	850-0045	4	Washer, Lock - Spring (5/16")
19	526-0115	4	Washer, Flat (11/32" ID x 11/16" OD x 1/16" Thk)
20	211-0364	1	Bell, End (Includes 4-516-0196
	222 0001	-	Alignment Pins)
21	232-0596	1	Clip, Bearing Retainer
22		_	BRUSH (Includes Parts Harked †)
	212-0361	1	Top
	212-0345	1	Right Side
	212-0352	1	Bottom
	212-0353	1	Left Side
23	815-0341	4	*Screw, Cap - Hex Head - Brass (#10-32 x 1")
24	853-0008	8	tWasher, Lock - ET (#10)
25	871-0010	4	thut, Hex - Brass (#10-32)
26	853-0008	4	tWasher, Lock - ET (#10)
27	526-0049	4	thasher Flat - Brass / 200 ID v
	00.3	•	7/16" OD x 1/32" Thk)
29	214-0095	4	tBrush, Commutator (DC)
30	214-0096	4	tBrush, Collector Ring (AC)
31	212-1232	12	tSpring, Brush
32	815-0359	15	Screw, Cap - Hex Head - Locking
			(#10-32 x 7/8")

<sup>\* -</sup> Parts Included in Armature Assembly.† - Parts Included in Generator Brush Blocks.



Ref. No.	Part No.	Qty. Used	Part Description
33	SUPPORT,	GENERATOR	
	232-2619	1	Spec A
	402-0475	2	Begin Spec B
34	850-0050	2	Washer, Lock - Spring (3/8")
35	800-0051	2	Screw, Cap - Hex Head (3/8-16 x 1-1/4")
36	205-0090	1	Fan, Cooling
37	850-0055	. 1	Washer, Lock - Spring (7/16")
38	870-0203	1	Nut, Hex (7/16-20)
39	232-2107	1	Cover, Generator
40	850-0040	2	Washer, Lock - Spring (1/4")
41	812-0156	2	Screw, Machine - Round Head (1/4-20 x 1-1/2")
42	234-0362	1	Wrapper, Generator
43	338-1099	1	Harness, Wiring

<sup>\* -</sup> Parts Included in Armature Assembly.† - Parts Included in Generator Brush Blocks.




#### **Control**

Ref. No.	Part No.	Qty. Used	Part Description
1	301-4446	1	Box, Control
2	301-4442	1	Panel, Control
3	COVER, CONTRO	L (Inc	ludes AC Schematic)
	301-4466	ì	Prior to Serial #D783330433 During Spec A
	301-4543	1	Begin Serial #D783330433 During Spec A
	301-4894	1	Begin Spec B
4	301-4441	ī	Plate, Control
6	815-0350	ī	Screw, Tapping - Slotted HWH (#10-32 x 3/8")
7	518-0056	1	Screw, Wing (#10-32 x 1/2")
8	RELAY, START	SOLENO	ID .
			Spec A
	307-1498	1	Sets Without Start-Disconnect
	307-1617	1 .	Sets With Start-Disconnect
	307-1617	1	Begin Spec B
9	821-0009	6	Screw, Cap - HWH
			$(1/4-20 \times 3/8")$
10	307-1575	2	<pre>t**Relay, Ignition (Crank Ignition     and Run Ignition)</pre>
11	815-0340	2	Screw, Machine - Round Head (#10-32 x 3/8")
12	870-0131	2	Nut, Hex with ET (#10-32)
13	308-0383	1	Switch, Start-Stop
14	321-0175	2	Holder, Fuse
15	321-0174	2	Fuse (5 Ampere)
16	508-0208	. 1	Bushing, Insulating - Nylon (3/4" Hole)
17	331-0088	1	Bushing, Insulating
18	508-0191	1	Bushing, Insulating - Nylon (7/8" Hole)
19	304-0580	1	Insulator, Resistor Hounting
20	RESISTOR		•
			Spec A
	352-0160	1	*†120-0hm, 5 Watt - Sets Without Start-Disconnect
	352-0161	1	°100-0hm, 5 Watt - Sets with Start-Disconnect
	352 <del>-</del> 0161	1	°Begin Spec B
	304-0431	1	*150-0hm, 5 Watt - Begin Spec A
21	812-0087	1	Screw, Machine - Round Head (#8-32 x 1-1/2")
22	870-0221	2	Nut, Hex with ET (#8-32)
23	821-0004	5	Screw, Cap - Hex Head (#10-32 x 5/16")
24	856-0003	2	Washer, Lock - EIT (#10)


<sup>\* -</sup> Parts Included in 338-1084 Wiring Harness.
† - Parts Included in 338-1169 Wiring Harness.
\* - Parts Included in 338-1265 Wiring Harness.

## Control



#### Control

Ref. No.	Part No.	Qty. Used	Part Description
25	BLOCK, TERM	INAL	
	332-0699	1	*6 Place - Prior to Serial #D783330433 During Spec A
	332-0254	1	4 Place
26	812-0066	2	Screw, Machine - Round Head (#6-32 x 3/4")
27	853-0003	2	Washer, Lock - ET (#6)
28	860-0005	2	Nut, Hex (#6-32)
30	HARNESS WIR	ING - CON	TROL
			Prior to Serial #D783332233 During
		_	Spec A (Includes Parts Marked *)
	338-1084	1	Sets Without Start-Disconnect
	338-1084	1	Sets With Start-Disconnect
			(Also Order Qty. 1 -352-0161 Resistor)
			Begin Serial #D783332233
	220 1150	•	During Spec A
	338-1169	1	Sets Without Start-Disconnect
	220 1665	4	(Includes Parts Marked †)
	338-1265	1	Sets With Start-Disconnect)
	220 1265	•	(Includes Parts Marked °)
	338-1265	1	Begin Spec B (Includes Parts
31	323-1088	3	Marked °) Nut, Wire
32	332-1043	2	*Jumper, Terminal Block
33	357-0030		*t°Rectifier, Diode
33 34	338-1078	1	Harness, Wiring (Includes Parts
<b>5</b> 4	330 1070	-	Marked +) - Prior to Serial
			#D783330433 During Spec A
35	323-0440	1	t°+Housing, Connector Pin
36	323-0488		t°+Pin, Connector - Female
37	CIRCUIT, BRI		, and the second
			Spec A
	320-0734	1	Kit, Replacement (Replaces Qty.
			1 - 40 Amp Breaker) (Includes
			Parts Harked #)
			Begin Spec B
		_	60 Hertz Sets
	320-0544	1	#30 Amp Breaker
	320-0692	1	#20 Amp Breaker
20	320-0692	2	50 Hertz Sets
<b>3</b> 8	STRIP, TERM		•
	332-2099	1	Spec A
	332-2099	1	Begin Spec B 60 Hertz Sets
		1	
	332-2288	1	50 Hertz Sets
± . D=:	nto Included	: 110 10	OA Minima Hannana
			84 Wiring Harness.
			69 Wiring Harness. 65 Wiring Harness.
			os wiring Harness. 78 Wiring Harness
# - Pai	rts Included	333 10 in 320-07	34 Circuit Breaker Kit



#### Control


Ref. No.	Part No.	Qty. Used	Part Description
39	508-0015	1	Washer, Fibre
43	HARNESS,	WIRING - R	EMOTE (Includes Parts Marked %)
	338-1082	1	6 Inches Long
	338-1080	1	10 Ft Optional
	338-1081	1	30 Ft Optional
44	323-0400	1	%Housing, Connector Pin
45	323-0500	5	%Pin, Connector - Male
46	332-0142	1	Terminal, Solderless

- \* Parts Included in 338-1084 Wiring Harness.
- t Parts Included in 338-1169 Wiring Harness.

   Parts Included in 338-1265 Wiring Harness.


  + Parts Included in 338-1078 Wiring Harness
- # Parts Included in 320-0734 Circuit Breaker Kit.
- % Parts Included in 338-1080, 338-1081, 338-1082 Wiring Harness.

### Air Housing



Ref. No.	Part No.	Qty. Used	Part Descriptio <del>n</del>
	821-0008	4	Screw, Cap - Hex Head (1/4 - 20 x 5/16")
2	SCROLL ASSEMBLY		
	134-3149	1	Includes Guard (Prior to 6/83)
	134-3151	1	Excludes Guard (Begin 6/83)
3	815-0261	2	Screw, Cap - Hex Head (1/4 - 20 x 1/2")
4	BACKPLATE, SCROLI	L	
	134-3257	1	Spec A
	134-3688	1	Begin Spec B
5	815-0261	4	Screw, Cap - Hex Head (1/4 - 20 x 1/2")
6	HOUSING, CYLINDER	R AIR	
	134-3137	1	Spec A
	134-3701	1	Begin Spec B
7	HOUSING, CYLINDE	R AIR	- RIGHT SIDE
	134-3480	1	Spec A
	134-3700	1	Begin Spec B
8	GUARD, SCROLL		
	134-3418	1	Screen (Prior to 6/83)
	134-4316	1	Wire (Begin 6/83)
9	815-0421	4	Screw, Self-Tapping - Hex Head - WET
	•		$(10 - 16 \times 1/2")$

### **Exhaust System**




Ref. No.	Part No.	Qty. Used	Part Description
1	154-1947	1	Manifold, Exhaust
2	154-1725	2	Gasket, Exhaust Manifold
3	800-0026	4	Screw, Cap - Hex Head (5/16-18 x 3/4" lg)
4	850-0045	4	Washer, Lock - Spring (5/16")

#### **Optional Equipment Parts Section**

This section contains illustrated parts listings of factory installed options for these Generator Sets. Options may not be applicable to all models; for field conversions, additional parts are usually required. Optional parts listed in this section are in addition or in place of those shown in the standard Generator Set parts section.


## Optional Remote Starting Control



Ref. No.	Part No.	Qty. Used	Part Description
NOTE:			of three types of Control Packages.
NUIE.	Use applica	ble contr	ol package when ordering components.
1	308-0165	1	Control Package, Remote Starting (Includes Parts Marked *)
2	300-0985	1	Control Package, Remote Starting (Includes Parts Marked +)
3	300-0986	1	Control Package, Remote Starting
			Deluxe (Includes Parts Marked t)
4	308-0154	1	*Switch, Toggle (SPDT)
5	308-0168	1	*Plate, Mounting
6	815-0385	2	*Screw, Machine - Round Head (#6-32 x 1/2")
7	308-0341	1	+tSwitch, Rocker with Light
8 9	301-3566	1	+Panel, Control
9	301-3606	1	†Panel, Control
10	302-0885	1	tMeter, Time Totalizing
11	302-0888	1	tMeter, Battery Condition
12	359-0034	1	tDiode and Lead
13	815-0385	2	tScrew, Machine - Round Head (#6-32 x 1/2")
14	860-0005	2	†Nut, Hex (#6-32)
15	815-0380	2	Screw, Tapping (#5 x 1/2")
		_	MOTE (Not Shown)
	338-1080	1	10 Feet Long
	338-1081	ī	30 Feet Long
	338-1082	1	6 Inches Long
* - Par	ts Included	in 308-01	65 Control Package.

<sup>\* -</sup> Parts Included in 308-0165 Control Package.
+ - Parts Included in 300-0985 Control Package.
† - Parts Included in 300-0986 Deluxe Control Package.


Optional LP Fuel System Begin Spec B 5.0 BGA



#### Optional LP Fuel System Begin Spec B 5.0 BGA

Ref. No.	Part No.	Qty. Used	Part Description
1	140-1719	1	Adapter, Air Duct
2	148-0840	1	Adapter, Carburetor (Includes Gaskets, Screws, 3-#10 Lock Washers)
3	503-1039	1	Hose, Breather (7/16 x 1-1/2")
4	123-1484	1	Tube, Breather (Copper)
5	509-0145	1	Seal, O-Ring
6 7	502-0028	1	Plug, Pipe - Hex Head (1/8")
7	502-0575	1	Elbow, Hose - 45°
8	815-0389	1	Screw, Thd. Form Choke Shaft Hole (1/4-20 x 5/8")
9	503-1048	1	Hose, Fuel (1/2" ID x 30" Lg)
10	503-0032	2	Clamp, Hose
11	502-0238	1	Connector, Hose (1/2")
12	148-0311	1	Regulator, Gas
13	148-0852	1	Bracket
14	800-008	2	Screw, HHC (1/4-20 x 1-1/4")
15	526-0018	2	Washer, Flat (17/64" ID x 5/8" OD x 1/16" Thk)
16	850-0040	2	Washer, Lock (1/4")
17	862-0001	2	Nut, Hex (1/4-20)
1ε	505-0057	1	Plug, Square Hd (1/8")
19	307-1881	1	Solenoid Assembly
20	307-0312	1	Valve, Magnetic
21	505-0332	1	Nipple, Pipe (3/4 x 3" Lg)
22	505-0051	2 1	Elbow, Street (90° x 3/4")
23	502-0395		Connector, Vent Hose (1/4")
24	503-1016	1	Hose, 0il (1/2" ID x 12")
25	800-0028	2 2	Screw, HHC (5/16-18 x 1")
26	870-0257	2	Nut, Hex (5/16-18)


#### Optional Exhaust System (Non-UL Listed and CSA Certified)



# Optional Exhaust System (Non-UL Listed and CSA Certified)

Ref. No.	Part No.	Qty. Used	Part Description
1	154-1947	1	Hanifold, Exhaust
2	800-0026	4	Screw, Cap - Hex Head (5/16-18 x 3/4")
3	850-0045	4	Washer, Lock - Spring (5/16")
4	154-1725	2	Gasket, Exhaust Manifold
5 6	154-2061	1	Gasket, Exhaust
6	TUBE, EXHAU	ST	•
			Spec A
	154-1917	1	17" Long
	154-2017	1 1	14" Long
			Begin Spec B
	154-2167	1	15-1/2" Long
	154-2143	1 1	12-1/2" Long
7	0800-0030	2	Screw, Cap - Hex Head (5/16-18 x 1-1/4" lg)
8	850-0045	2	Washer, Lock - Spring (5/16")
9	862-0015	2	Nut, Hex (5/16-18)
<b>1</b> 0	155-1239	1	Clamp, Muffler
11	155-1234	1	Hanger, Huffler
12	MUFFLER, EX	HAUST	
	155-1258	1	End Inlet
	155-1520	1	Center Inlet - Optional


Optional
Exhaust System
(UL Listed and CSA Certified)



# Optional Exhaust System (UL Listed and CSA Certified)

	(0	L Listed and	OOA Common
Ref. No.	Part No.	Qty. Used	Part Description
1	MANIFOLD, EXH	HAUST	
	154-1947	1	Prior to 6/83
	154-2425	1	Includes Heat Shield(Begin 6/83)
2	800-0026	4	Screw, Cap-Hex Head (5/16-18 x 3/4)
3	850-0045	4	Washer, Lock-Spring(5/16")
4	154-1725	2	Gasket, Exhaust Manifold
5	154-2061	ī	Gasket, Exhaust Tube
5 6	TUBE, EXHAUST	Γ	•
	<b>,</b> -		Spec A
	154-1917	1	17" Long
	154-2017	1	14" Long
			Begin Spec B
	154-2167	1	Ĭ5-1/2" Long (Straight)
	154-2143	1 1	12-1/2" Long (Straight)
	154-2226	1	90° Bend-With Attached Clamp
			(4" Long)
	154-2554	1	90° Bend-With Attached Clamp
			(18" Long)
7	800-0030	2	Screw, Cap-Hex Head
			$(5/16-18 \times 1\frac{1}{4}" \text{ Long})$
8	850-0045	2	Washer, Lock-Spring(5/16")
9	862-0015	2	Nut, Hex (5/16-18")
10	CLAMP, MUFFL	_ER	·
	155-1015	1	1½" Diameter
	155-1239	1	1 5/8" Diameter
11	155-1234	1	Hanger, Muffler
12	MUFFLER, EXI	HAUST	
	155-1258	1	End Inlet
	155-1520	1	Center Inlet (Used with Straight
			Exhaust Tube)
	<b>155-191</b> 0	1	Center Inlet (Used With 90° Bend
			Exhaust Tube)
13	SHIELD, HEAT	Γ	
	154-1980	1	Spec A
	154-2146	1	Begin Spec B
14	821-0010	3	Screw, Cap-Hex Head Locking (4-20 x ½)
15	154-1972	1	Shield, Heat(Prior to 6/83)
16	503-0107	$\bar{1}$	Clamp, Shield To Exhaust Tube
17	154-1883	ī	Bracket, Heat Shield-Left Side(Prior to 6/83)
18	154-1886	$\bar{1}$	Bracket, Heat Shield-Right Side(Prior To 6/83)
19	821-0010	1	Screw, Ćap-Locking Head(4-20 x½")

## Optional Carburetor Air Preheater



FS	1077
----	------

Ref. No.	Part No.	Qty. Used	Part Description
	140-1673	1	Kit, Carburetor Air Preheater
1	140-0788	1	Control, Air Temperature
			(Includes Parts Harked *)
2	140-0785	1	*Housing, Control
3	140-0782	1	*Shutter
4	140-0786	1	*Spring, Shutter Return
5	140-0784	1	*Plunger
6	140-0808	1	*Spacer, Vernatherm
7	140-0787	1	*Spring, Vernatherm
8	518-0205	2	*Ring, Řetaining
9	870-0195	1	*Palnut
10	309-0181	1	*Vernatherm
11	140-1672	1	Wrapper, Air Cleaner
12	503-0004	3	Clamp, Hose
13	503-0981	1	Hose, Duct
14	503-0980	1	Hose, Duct
15	332-2247	1	Clamp, Loop

 $<sup>\</sup>star$  - Parts Included in 140-0788 Air Temperature Control.

#### Paint

Ref. No.	Part No.	Qty. Used	Part Description
	525-0137	1	Paint, Touch-up (Non-Metallic Green) - 13 oz. Pressurized Can
	525-0305	1	Paint, Touch-up (Metallic Green) -